







Navigation and Function Tips

- To:** Open a menu in any application, **Do:** press the  key.
- Access options and available actions, **Do:** press the  key.
- Close a menu or move back a screen, **Do:** press the  key.
- Return to the Home screen, **Do:** press the  key.
- Show a description on the shortcut bar, **Do:** touch and hold the shortcut.
- Hide the keyboard, **Do:** slide your finger down.

Picture Tips

- To:** Take a picture, **Do:** press the **Right Convenience** key.
- Lock the focus on a subject before you take a picture, **Do:** press the **Right Convenience** key halfway.

Music Tips

- To:** Pause a song or video, **Do:** press the  key.
- Resume playing a song or video, **Do:** press the  key again.

For more actions, see the setup wizard on your BlackBerry® smartphone.

For more information, please visit www.blackberry.com/uk

 **BlackBerry Storm**

©2009 Research In Motion Limited. All Rights Reserved. BlackBerry®, RIM®, Research In Motion®, SureType®, SurePress™ and related trademarks, names and logos are the property of Research In Motion Limited and are registered and/or used in the U.S. and countries around the world.



BlackBerry Storm smartphone

Tips

www.blackberry.com/uk



 **BlackBerry Storm**



BlackBerry® Storm™ smartphone

Tips



Lock key

Lock the device
Turn on standby mode

Mute key

Play/pause a media file
Mute a call

Left Convenience key

Open the voice dialing application

Headset Jack

Volume keys

Right Convenience key

Open the camera Autofocus
Take a picture

Micro-USB port

Menu key

Open the menu in an application

Escape key

Move back a screen
Close a menu

Send key

Open the phone
Call a highlighted phone number

End/Power key

Return to the Home screen
End a call
Turn on/off your device

Getting Started

To set up the BlackBerry® Storm™ smartphone, complete the following tasks. You can also see the [Getting Started Guide](#) (comes with the smartphone) or click [Help](#) on the device for step-by-step instructions.

- Insert the SIM card.
- Insert the battery.
- Charge the battery.
- Complete the setup wizard.

Touchscreen Tips

To:

Select an item,

Highlight an item or place the cursor,

Scroll down,

Scroll up,

Move down a screen,

Move up a screen,

Move to the next item,

Move to the previous item,

Do:

click (press) the item.

touch the screen lightly.

touch and hold near the bottom of the screen.

touch and hold near the top of the screen.

slide your finger up quickly.

slide your finger down quickly.

slide your finger to the left quickly.

slide your finger to the right quickly.